

RACAL INSTRUMENTS™
1260-54
TREE MULTIPLEXER
MODULE

Publication No. 980673-009 Rev. A

Astronics Test Systems Inc.

4 Goodyear, Irvine, CA 92618

Tel: (800) 722-2528, (949) 859-8999; Fax: (949) 859-7139

atsinfo@astronics.com atssales@astronics.com
atshelpdesk@astronics.com <http://www.astronictestsystems.com>

**THANK YOU FOR PURCHASING THIS
ASTRONICS TEST SYSTEMS PRODUCT**

For this product, or any other Astronics Test Systems product that incorporates software drivers, you may access our web site to verify and/or download the latest driver versions. The web address for driver downloads is:

<http://www.astronicstestsystems.com/support/downloads>

If you have any questions about software driver downloads or our privacy policy, please contact us at:

atsinfo@astronics.com

WARRANTY STATEMENT

All Astronics Test Systems products are designed to exacting standards and manufactured in full compliance to our AS9100 Quality Management System processes.

This warranty does not apply to defects resulting from any modification(s) of any product or part without Astronics Test Systems express written consent, or misuse of any product or part. The warranty also does not apply to fuses, software, non-rechargeable batteries, damage from battery leakage, or problems arising from normal wear, such as mechanical relay life, or failure to follow instructions.

This warranty is in lieu of all other warranties, expressed or implied, including any implied warranty of merchantability or fitness for a particular use. The remedies provided herein are buyer's sole and exclusive remedies.

For the specific terms of your standard warranty, contact Customer Support. Please have the following information available to facilitate service.

1. Product serial number
2. Product model number
3. Your company and contact information

You may contact Customer Support by:

E-Mail:	atshelpdesk@astronics.com	
Telephone:	+1 800 722 3262	(USA)
Fax:	+1 949 859 7139	(USA)

RETURN OF PRODUCT

Authorization is required from Astronics Test Systems before you send us your product or sub-assembly for service or calibration. Call or contact Customer Support at 1-800-722-3262 or 1-949-859-8999 or via fax at 1-949-859-7139. We can also be reached at: atshelpdesk@astronics.com.

If the original packing material is unavailable, ship the product or sub-assembly in an ESD shielding bag and use appropriate packing materials to surround and protect the product.

PROPRIETARY NOTICE

This document and the technical data herein disclosed, are proprietary to Astronics Test Systems, and shall not, without express written permission of Astronics Test Systems, be used in whole or in part to solicit quotations from a competitive source or used for manufacture by anyone other than Astronics Test Systems. The information herein has been developed at private expense, and may only be used for operation and maintenance reference purposes or for purposes of engineering evaluation and incorporation into technical specifications and other documents which specify procurement of products from Astronics Test Systems.

TRADEMARKS AND SERVICE MARKS

All trademarks and service marks used in this document are the property of their respective owners.

- Racal Instruments, Talon Instruments, Trig-Tek, ActivATE, Adapt-A-Switch, N-GEN, and PAWS are trademarks of Astronics Test Systems in the United States.

DISCLAIMER

Buyer acknowledges and agrees that it is responsible for the operation of the goods purchased and should ensure that they are used properly and in accordance with this document and any other instructions provided by Seller. Astronics Test Systems products are not specifically designed, manufactured or intended to be used as parts, assemblies or components in planning, construction, maintenance or operation of a nuclear facility, or in life support or safety critical applications in which the failure of the Astronics Test Systems product could create a situation where personal injury or death could occur. Should Buyer purchase Astronics Test Systems product for such unintended application, Buyer shall indemnify and hold Astronics Test Systems, its officers, employees, subsidiaries, affiliates and distributors harmless against all claims arising out of a claim for personal injury or death associated with such unintended use.

FOR YOUR SAFETY

Before undertaking any troubleshooting, maintenance or exploratory procedure, read carefully the **WARNINGS** and **CAUTION** notices.



CAUTION
RISK OF ELECTRICAL SHOCK
DO NOT OPEN



This equipment contains voltage hazardous to human life and safety, and is capable of inflicting personal injury.



If this instrument is to be powered from the AC line (mains) through an autotransformer, ensure the common connector is connected to the neutral (earth pole) of the power supply.



Before operating the unit, ensure the conductor (green wire) is connected to the ground (earth) conductor of the power outlet. Do not use a two-conductor extension cord or a three-prong/two-prong adapter. This will defeat the protective feature of the third conductor in the power cord.



Maintenance and calibration procedures sometimes call for operation of the unit with power applied and protective covers removed. Read the procedures and heed warnings to avoid “live” circuit points.

Before operating this instrument:

1. Ensure the proper fuse is in place for the power source to operate.
2. Ensure all other devices connected to or in proximity to this instrument are properly grounded or connected to the protective third-wire earth ground.

If the instrument:

- fails to operate satisfactorily
- shows visible damage
- has been stored under unfavorable conditions
- has sustained stress

Do not operate until performance is checked by qualified personnel.

EC Declaration of Conformity

We

Astronics Test Systems
4 Goodyear
Irvine, CA

declare under sole responsibility that the

1260-54 Tree Multiplexer Module
P/N 404768

conforms to the following Product Specifications:

Safety: EN 61010-1

EMC: CISPR 11:1990/EN 55011 (1991): Group 1 Class A
IEC 801-2:1991/EN 50082-1 (1992): 4 kV CD, 8 kV AD
IEC 801-3:1984/EN 50082-1 (1992): 3 V/m, 27-500 MHz
IEC 801-4:1988/EN 50082-1 (1992): 1 kV

Supplementary Information:

The above specifications are met when the product is installed in an Astronics Test Systems certified mainframe with faceplates installed over all unused slots, as applicable.

The product herewith complies with the requirements of the Low Voltage Directive 73/23/EEC and the EMC Directive 89/336/EEC.

Irvine, CA, January 24, 1996


Quality Manager

This page was left intentionally blank.

NOTE FOR SYSTEMS WITH 1260-OPT 01T

The “Module-Specific Syntax” section of this manual shows the command syntax for the 1260-01S Smart Card. If you are using the newer 1260-01T Smart Card, the commands will NOT work as shown.

Consult the 1260-01T Manual for a description of the commands which may be used with the 1260-01T Smart Card.

The channel numbers described in this manual are valid for the 1260-01T. The channel numbers continue to be used for the 1260-01T.

The syntax of the commands which use channel numbers has changed for those cards controlled by the 1260-01T.

The new syntax used to close a channel is:

CLOSE (@ <module address> (<channel>))

For example, with for a relay module whose <module address> is set to 7, closing <channel> 0 is performed with the command:

CLOSE (@ 7 (0))

Using the older 1260-01S, the command would be (as shown in this manual):

CLOSE 7.0

Many other command syntax differences exist. Please consult chapter 2 of the 1260-01T manual for a description of the commands which are available for the 1260-01T.

Control Information for the 1260-54

The following information describes the control-register-to-relay-channel mapping for a 1260-54 Relay Module. This information may be used to control a 1260-54 when using a 1260-01T in the register-based mode of operation.

A channel within each 1x4 MUX may be selected by programming either 1 or 2 Control Registers. Selecting one channel in each MUX will open all others in that MUX.

Each Control Register is located 2 addresses from the previous Control Register. That is, each Control Register is located at an odd address. This is shown in Table 2-2 of the 1260-01T manual. Control Register 0 is located at the "Base A24 Address" for the module. Consult the "Register-Based Operation" Section of Chapter 2 of the 1260-01T manual for a description of calculating control register addresses.

Each Control Register may also control several different MUXes. For this reason it is necessary to form the new Control Register values by performing the following steps:

- Read the present Control Register values
- Invert the Control Register value (the hardware inverts the present value on reading)
- AND the present data with an AND mask from the table below
- OR the present data with the OR mask from the table below.

For example, from the table below, to select channel 10 (MUX #1, channel 0 to COM), we must write to both Control Register #0 and Control Register #1. The Control Register #0 AND mask is 3F (hexadecimal), while the Control Register #1 AND mask is F0 (hexadecimal). Similarly, the Control Register #0 OR mask is 40 (hexadecimal), while the Control Register #1 OR mask is 0C (hexadecimal). Therefore, to select channel 10, perform the following sequence of operations:

- Read the present value of Control Register #0
- Perform a 1's complement (invert) of each of the bits of this register
- AND the value with 3F hexadecimal, clearing the most significant 2 bits
- OR the value with 40 hexadecimal
- Write the value just created back to Control Register #0
- Read the present value of Control Register #1
- AND the value with F0 hexadecimal, clearing the least significant 4 bits
- OR the value with 0C hexadecimal
- Write the value just created back to Control Register #1

In 'C', this can be represented (using ViIn8() and ViOut8() to write) as follows:

```
ViAddr control_reg_0, control_reg_1;
ViUInt8 creg0_val, creg1_val;
ViStatus error;
ViSession hdl;          /* this is from the viOpen() function */

control_reg_0 = (module address of card x 0x400) + 1;
control_reg_1 = control_reg_0 + 2;
```

```

error = ViIn8(hdl, control_reg_0, &creg0_val);
creg0_val = ~ creg0_val;      /* invert the data read back */
creg0_val &= 0x3F;           /* AND with 3F hex */
creg0_val |= 0x40;          /* OR with 40 hex */
error = viOut8(hdl, control_reg_0, creg0_val);

```

```

error = ViIn8(hdl, control_reg_1, &creg1_val);
creg1_val = ~ creg1_val;      /* invert the data read back */
creg1_val &= 0xF0;           /* AND with F0 hex */
creg1_val |= 0x0C;          /* OR with 0C hex */
error = Out8(hdl, control_reg_1, creg1_val);

```

Note that for each MUX, using a value of 0 for the OR mask for all Control Registers used for that MUX will open ALL 4 channels of that MUX.

The table below shows the mapping from logical channels to control bits. The logical channels are used when operating the relay module in message-based mode. The control bits within the Control Registers are used to operate the module in register-based mode. The table shows holds one or two entries, showing the Control Register, the AND mask, and the OR mask to use to select the desired MUX relay closures.

Channel	Control Register	AND Mask (hex)	OR Mask (hex)
00	0	C0	31
01	0	C0	22
02	0	C0	14
03	0	C0	08
10	0	3F	40
	1	F0	0C
11	0	3F	80
	1	F0	08
12	0	3F	00
	1	F0	05
13	0	3F	00
	1	F0	02
20	1	0F	10
	2	FC	03
21	1	0F	20
	2	FC	02
22	1	0F	40
	2	FC	01
23	1	0F	80
	2	FC	00
30	2	03	C4
31	2	03	88
32	2	03	50
33	2	03	20
40	3	C0	31
41	3	C0	22
42	3	C0	14
43	3	C0	08
50	3	3F	40
	4	F0	0C
51	3	3F	80
	4	F0	08
52	3	3F	00
	4	F0	05
53	3	3F	00
	4	F0	02

This page was left intentionally blank.

Table of Contents

Chapter 1	1-1
Introduction	1-1
1260-54 1GHz Tree Multiplexer Module	1-1
Specifications	1-2
Chapter 2	2-1
INSTALLATION INSTRUCTIONS	2-1
Unpacking and Inspection	2-1
Option 01 Installation	2-1
Module Installation	2-1
Chapter 3	3-1
MODULE SPECIFIC SYNTAX	3-1
1260-54 Commands	3-1
Syntax	3-1
OPEN	3-1
CLOSE	3-2
PSETUP	3-2
PDATAOUT	3-2
Chapter 4	4-1
OPTIONAL HARNESS ASSEMBLIES	4-1

List of Figures

Figure 1-1, 1260-54 1-1

Figure 1-2, 1260-54 Functional Diagram 1-2

Figure 1-3, 1260-54 Front Panel..... 1-4

DOCUMENT CHANGE HISTORY

Revision	Date	Description of Change
A	01/18/10	Revised per EO 30017 Revised format to current standards. Company name revised throughout manual. Manual now revision letter controlled. Added Document Change History Page iii. Back of cover sheet. Revised Warranty Statement, Return of Product, Proprietary Notice and Disclaimer to current standards. (Chap2-1) Unpacking and inspection. Revise to current standards. Removed Reshipment Instructions in (Chap. 2-1) and removed (Chap 5). Information. Now appears in first 2 sheets behind cover sheet. Updated table of contents to reflect changes made. . Added company name o footer opposite of Page no's i thru iv.

This page was left intentionally blank.

Chapter 1

INTRODUCTION

1260-54 1GHz Tree Multiplexer Module

The 1260-54 provides six 1 x 4 tree multiplexers. Each channel has the capability of being terminated into an optional 50 Ω SMB terminator.




Figure 1-1, 1260-54




Figure 1-2, 1260-54 Functional Diagram

Specifications

Minimum Option 01 Firmware Revision	17.1
User Connector	SMC Caution: Mating Connector engagement should not exceed 16in. oz. Torque maximum.
Maximum Switchable Voltage (Signal to Ground)	30VDC, 100VAC RMS

Maximum Switchable Current Per Channel	1.5ADC, 1.5A RMS
Maximum Switchable Power Per Channel	60W DC, 60VA AC, 60W RF Power
DC Performance	
Path Resistance	<1 Ω
AC Performance	
Bandwidth, (-3 dB, 50 Ω Termination)	1.3 GHz
Insertion Loss, (50 Ω Termination)	<.50dB at 100MHz <1.5dB to 500 MHz <2.0dB to 1GHz
Crosstalk Across Groups (50 Ω Termination)	<-100dB to 100MHz <-80dB to 500MHz <-60dB to 1GHz <-50dB to 1.3GHz
Isolation Between Channels (50 Ω Termination)	<-80dB at 100MHz <-65dB at 500MHz <-55dB at 1GHz <-40dB at 1.3GHz
VSWR (50 Ω Termination)	1.1:1 at 100MHz 1.25:1 at 500MHz 1.75:1 at 1GHz 1.75:1 at 1.3GHz
Switching Time	<10mS
Cooling Requirements	
Airflow	4 litres/sec
Backpressure	0.5mmH ₂ O
Power Requirements (I_{pm})	
+5 V	0.4A (2.8A with Option 01)
+12 V	10 mA per relay
Weight	1.17 Kg (2.59 lb) without Option 01 1.29 Kg (2.87 lbs) with Option 01




Figure 1-3, 1260-54 Front Panel

Chapter 2

INSTALLATION INSTRUCTIONS

Unpacking and Inspection

1. Remove the 1260-54 module and inspect it for damage. If any damage is apparent, inform the carrier immediately. Retain shipping carton and packing material for the carrier's inspection.
2. Verify that the pieces in the package you received contain the correct 1260-54 module option and the 1260-54 Users Manual. Notify Customer Support if the module appears damaged in any way. Do not attempt to install a damaged module into a VXI chassis.
3. The 1260-54 module is shipped in an anti-static bag to prevent electrostatic damage to the module. Do not remove the module from the anti-static bag unless it is in a static-controlled area.

Option 01 Installation

Installation of the Option 0 1 into the 1260-54 is described in the Installation section of the 1260 Series VXI Switching Cards Manual.

Module Installation

Installation of the 1260-54 Switching Module into a VXI mainframe, including the setting of DIP switches, is described in the Installation section of the 1260 Series VXI Switching Cards Manual. The ID byte DIP switches, SW1-5 and SW 1-6, should be set OFF.

This page was left intentionally blank.

Chapter 3

MODULE SPECIFIC SYNTAX

1260-54 Commands

The 1260-54 RF Multiplexer supports the OPEN, CLOSE, PSETUP, RESET and PDATAOUT commands.

NOTE:

The 1260-54 Coaxial switching module is supported by the Option 01 Operating Systems at Revision levels 3.1 and above.

Syntax

The module specific syntax for the 1260-54 RF Multiplexer is as follows:

OPEN

OPEN <module address>.<channel>[;<module address>.<channel>]

where <module address> is the address.

<channel> is the relay to be closed to connect an input to the output.

Note that Channels remain closed until opened by an OPEN command.

The range of values for <channel> is:

00-03

10-13

20-23

30-33

40-43

50-53

CLOSE

The Module Specific Syntax for the CLOSE command is the same as for the OPEN command. Note each group of <channel> values contains five values. Using the highest value in each group, 04, 14, 24 etc, will give a connection to a "not connected" pin, i.e., open the path from input to output. This has the same effect using an OPEN command.

Connections between input and output are mutually exclusive within a group in the switch module. A CLOSE command will open an existing connection and close the new connection. An OPEN command will open any existing connection in the group and open circuit the Common connection.

The 1260-54 is restricted to the Break-Before-Make sequence mode.

PSETUP

The PSETUP command causes the specified module setup to be transmitted to the VXI Controller. The syntax used is:

PSETUP <module address>[;<module address>][;<module address>] where <module address> is the address.

The responses to the PSETUP command for the 1260-54 multiplexer is as follows:

<module address>. 1260-54 COAXIAL SWITCHING MODULE
<module address>.BBM
<module address>.END

PDATAOUT

The PDATAOUT command causes the specified module to transmit the CLOSED state of the relays fitted to the switching module to the 1260 Controller. The syntax used is:

PDATAOUT <module address>[.<module address>] [<module address>]

The responses to the PDATAOUT command is as follows:

<module address>.1260-54 RF MULTIPLEXER
<module address>.<channel>[,<channel>] [<channel>]
<module address>.END

The range of values for <channel> is:

00-03,10- 13,20-23,30-33,40-43 and 50-53.

Note that connections to the "not connected" pins within a group are not displayed.

Chapter 4

OPTIONAL HARNESS ASSEMBLIES

The following harness assemblies are used to connect 1260-54 to Freedom Series Test Receiver Interfaces.


Each harness documentation consists of an assembly drawing, parts list, system wire list and wire list.

407291, Virginia Panel, Inc. Series VP90 Interface Harness 4-3

407292, TTI Testron, Inc. Interface Harness 4-8
(TTI Receiver must be above chassis)

For more information on the complete line of Test Receiver Interface solutions, contact our Customer Support Department.

This page was left intentionally blank.



ENGINEERING PARTS LIST

DOC. NO. 407291

ENGINEERING WIRE LIST

WIRE	FROM	TO	TYPE	PART #	WIRE LEN	REFERENCE														
	BLK AA (J100)	Uxx-SLOT yy (E1-E15)	CABLE	407291		SYSTEM WIRE LIST														
	BLK AA (J101)	Uxx-SLOT yy (E16-E30)	CABLE	407291																
This system wirelist serves as a template for incorporating this harness assembly into the overall system wirelist. It does not in any way affect the fabrication of this harness assembly.																				
4 Goodyear St., Irvine, CA 92718 DOC. NO. 407291 <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 40%;">DOCUMENT TITLE</td> <td style="width: 10%;">SIZE</td> <td style="width: 15%;">CODE NO.</td> <td style="width: 20%;">DOCUMENT NO.</td> <td style="width: 15%;">REV</td> </tr> <tr> <td rowspan="2">HARNESS ASSEMBLY, 1260-54C, VP90</td> <td>A</td> <td>21793</td> <td>407291</td> <td>B</td> </tr> <tr> <td>DRN</td> <td></td> <td colspan="2">SHEET 3 of 5</td> </tr> </table>							DOCUMENT TITLE	SIZE	CODE NO.	DOCUMENT NO.	REV	HARNESS ASSEMBLY, 1260-54C, VP90	A	21793	407291	B	DRN		SHEET 3 of 5	
DOCUMENT TITLE	SIZE	CODE NO.	DOCUMENT NO.	REV																
HARNESS ASSEMBLY, 1260-54C, VP90	A	21793	407291	B																
	DRN		SHEET 3 of 5																	

ENGINEERING WIRE LIST


WIRE	FROM	TO	TYPE	PART #	WIRE LEN	REFERENCE
1	J100-1 (602201-008)	E1 (600483)	COAX	602201-807	54"	CHANNEL 00
2	J100-2 (602201-008)	E2 (600483)	COAX	602201-807	54"	CHANNEL 01
3	J100-3 (602201-008)	E3 (600483)	COAX	602201-807	54"	CHANNEL 02
4	J100-4 (602201-008)	E4 (600483)	COAX	602201-807	54"	CHANNEL 03
5	J100-5 (602201-008)	E5 (600483)	COAX	602201-807	54"	COM 0
6	J100-6 (602201-008)	E6 (600483)	COAX	602201-807	54"	CHANNEL 10
7	J100-7 (602201-008)	E7 (600483)	COAX	602201-807	54"	CHANNEL 11
8	J100-8 (602201-008)	E8 (600483)	COAX	602201-807	54"	CHANNEL 12
9	J100-9 (602201-008)	E9 (600483)	COAX	602201-807	54"	CHANNEL 13
10	J100-10 (602201-008)	E10 (600483)	COAX	602201-807	54"	COM 1
11	J100-11 (602201-008)	E11 (600483)	COAX	602201-807	54"	CHANNEL 20
12	J100-12 (602201-008)	E12 (600483)	COAX	602201-807	54"	CHANNEL 21
13	J100-13 (602201-008)	E13 (600483)	COAX	602201-807	54"	CHANNEL 22
14	J100-14 (602201-008)	E14 (600483)	COAX	602201-807	54"	CHANNEL 23
15	J100-15 (602201-008)	E15 (600483)	COAX	602201-807	54"	COM 2
16	J100-16 NO CONNECT					
17	J100-17 NO CONNECT					
18	J100-18 NO CONNECT					
19	J100-19 NO CONNECT					
20	J101-1 (602201-008)	E16 (600483)	COAX	602201-807	54"	CHANNEL 30
21	J101-2 (602201-008)	E17 (600483)	COAX	602201-807	54"	CHANNEL 31
22	J101-3 (602201-008)	E18 (600483)	COAX	602201-807	54"	CHANNEL 32
23	J101-4 (602201-008)	E19 (600483)	COAX	602201-807	54"	CHANNEL 33
24	J101-5 (602201-008)	E20 (600483)	COAX	602201-807	54"	COM 3
25	J101-6 (602201-008)	E21 (600483)	COAX	602201-807	54"	CHANNEL 40
4 Goodyear St., Irvine, CA 92718						
DOCUMENT TITLE			SIZE	CODE NO.	DOCUMENT NO.	REV
HARNESS ASSEMBLY, 1260-54C, VP90			A	21793	407291	A
			DRN			SHEET 4 of 5

DOC NO. 407291

ENGINEERING WIRE LIST

WIRE	FROM	TO	TYPE	PART #	WIRE LEN	REFERENCE
26	J101-7 (602201-008)	E22 (600483)	COAX	602201-807	54"	CHANNEL 41
27	J101-8 (602201-008)	E23 (600483)	COAX	602201-807	54"	CHANNEL 42
28	J101-9 (602201-008)	E24 (600483)	COAX	602201-807	54"	CHANNEL 43
29	J101-10 (602201-008)	E25 (600483)	COAX	602201-807	54"	COM 4
30	J101-11 (602201-008)	E26 (600483)	COAX	602201-807	54"	CHANNEL 50
31	J101-12 (602201-008)	E27 (600483)	COAX	602201-807	54"	CHANNEL 51
32	J101-13 (602201-008)	E28 (600483)	COAX	602201-807	54"	CHANNEL 52
33	J101-14 (602201-008)	E29 (600483)	COAX	602201-807	54"	CHANNEL 53
34	J101-15 (602201-008)	E30 (600483)	COAX	602201-807	54"	COM 5
35	J101-16 NO CONNECT					
36	J101-17 NO CONNECT					
37	J101-18 NO CONNECT					
38	J101-19 NO CONNECT					
4 Goodyear St., Irvine, CA 92718						
DOCUMENT TITLE			SIZE	CODE NO.	DOCUMENT NO.	REV
HARNESS ASSEMBLY, 1260-54C, VP90			A	21793	407291	B.
			DRN			SHEET 5 of 5

DOC. NO. 407291



ENGINEERING PARTS LIST

[illegible]

ENGINEERING WIRE LIST

WIRE	FROM	TO	TYPE	PART #	WIRE LEN	REFERENCE
	BLK AAx PN 01 (J100)	Uxx-SLOT yy (CH00)	CABLE	407292		SYSTEM WIRE LIST
	BLK AAx PN 02 (J101)	Uxx-SLOT yy (CH01)	CABLE	407292		
	BLK AAx PN 03 (J102)	Uxx-SLOT yy (CH02)	CABLE	407292		
	BLK AAx PN 04 (J103)	Uxx-SLOT yy (CH03)	CABLE	407292		
	BLK AAx PN 05 (J104)	Uxx-SLOT yy (COM 0)	CABLE	407292		
	BLK AAx PN 06 (J105)	Uxx-SLOT yy (CH10)	CABLE	407292		
	BLK AAx PN 07 (J106)	Uxx-SLOT yy (CH11)	CABLE	407292		
	BLK AAx PN 08 (J107)	Uxx-SLOT yy (CH12)	CABLE	407292		
	BLK AAx PN 09 (J108)	Uxx-SLOT yy (CH13)	CABLE	407292		
	BLK AAx PN 10 (J109)	Uxx-SLOT yy (COM 1)	CABLE	407292		
	BLK AAx PN 11 (J110)	Uxx-SLOT yy (CH20)	CABLE	407292		
	BLK AAx PN 12 (J111)	Uxx-SLOT yy (CH21)	CABLE	407292		
	BLK AAx PN 13 (J112)	Uxx-SLOT yy (CH22)	CABLE	407292		
	BLK AAx PN 14 (J113)	Uxx-SLOT yy (CH23)	CABLE	407292		
	BLK AAx PN 15 (J114)	Uxx-SLOT yy (COM 2)	CABLE	407292		
	BLK AAx PN 16 (J115)	Uxx-SLOT yy (CH30)	CABLE	407292		
	BLK AAx PN 17 (J116)	Uxx-SLOT yy (CH31)	CABLE	407292		
	BLK AAx PN 18 (J117)	Uxx-SLOT yy (CH32)	CABLE	407292		
	BLK AAx PN 19 (J118)	Uxx-SLOT yy (CH33)	CABLE	407292		
	BLK AAx PN 20 (J119)	Uxx-SLOT yy (COM 3)	CABLE	407292		
	BLK AAx PN 21 (J120)	Uxx-SLOT yy (CH40)	CABLE	407292		
	BLK AAx PN 22 (J121)	Uxx-SLOT yy (CH41)	CABLE	407292		
	BLK AAx PN 23 (J122)	Uxx-SLOT yy (CH42)	CABLE	407292		
	BLK AAx PN 24 (J123)	Uxx-SLOT yy (CH43)	CABLE	407292		
	BLK AAx PN 25 (J124)	Uxx-SLOT yy (COM 4)	CABLE	407292		
4 Goodyear St., Irvine, CA 92718						
DOCUMENT TITLE			SIZE	CODE NO.	DOCUMENT NO.	REV
HARNESS ASSEMBLY, 1260-54C, TTI			A	21793	407292	A
			DRN		SHEET 3 of 5	

DOC. NO. 407292

ENGINEERING WIRE LIST

WIRE	FROM	TO	TYPE	PART #	WIRE LEN	REFERENCE
	BLK AAx PN 26 (J125)	Uxx-SLOT yy (CH50)	CABLE	407292		
	BLK AAx PN 27 (J126)	Uxx-SLOT yy (CH51)	CABLE	407292		
	BLK AAx PN 28 (J127)	Uxx-SLOT yy (CH52)	CABLE	407292		
	BLK AAx PN 29 (J128)	Uxx-SLOT yy (CH53)	CABLE	407292		
	BLK AAx PN 30 (J129)	Uxx-SLOT yy (COM 5)	CABLE	407292		
This system wirelist serves as a template for incorporating this harness assembly into the overall system wirelist. It does not in any way affect the fabrication of this harness assembly.						
4 Goodyear St., Irvine, CA 92718						
DOCUMENT TITLE			SIZE	CODE NO.	DOCUMENT NO.	REV
HARNESS ASSEMBLY, 1260-54C, TTI			A	21793	407292	A
			DRN			SHEET 4 of 5

DOC. NO. 407292

ENGINEERING WIRE LIST

WIRE	FROM	TO	TYPE	PART #	WIRE LEN	REFERENCE
1	J100	CH00	COAX	407263	40"	CHANNEL 00
2	J101	CH01	COAX	407263	40"	CHANNEL 01
3	J102	CH02	COAX	407263	40"	CHANNEL 02
4	J103	CH03	COAX	407263	40"	CHANNEL 03
5	J104	COM 0	COAX	407263	40"	COM 0
6	J105	CH10	COAX	407263	40"	CHANNEL 10
7	J106	CH11	COAX	407263	40"	CHANNEL 11
8	J107	CH12	COAX	407263	40"	CHANNEL 12
9	J108	CH13	COAX	407263	40"	CHANNEL 13
10	J109	COM 1	COAX	407263	40"	COM 1
11	J110	CH20	COAX	407263	40"	CHANNEL 20
12	J111	CH21	COAX	407263	40"	CHANNEL 21
13	J112	CH22	COAX	407263	40"	CHANNEL 22
14	J113	CH23	COAX	407263	40"	CHANNEL 23
15	J114	COM 2	COAX	407263	40"	COM 2
16	J115	CH30	COAX	407263	40"	CHANNEL 30
17	J116	CH31	COAX	407263	40"	CHANNEL 31
18	J117	CH32	COAX	407263	40"	CHANNEL 32
19	J118	CH33	COAX	407263	40"	CHANNEL 33
20	J119	COM 3	COAX	407263	40"	COM 3
21	J120	CH40	COAX	407263	40"	CHANNEL 40
22	J121	CH41	COAX	407263	40"	CHANNEL 41
23	J122	CH42	COAX	407263	40"	CHANNEL 42
24	J123	CH43	COAX	407263	40"	CHANNEL 43
25	J124	COM 4	COAX	407263	40"	COM 4
26	J125	CH50	COAX	407263	40"	CHANNEL 50
27	J126	CH51	COAX	407263	40"	CHANNEL 51
28	J127	CH52	COAX	407263	40"	CHANNEL 52
29	J128	CH53	COAX	407263	40"	CHANNEL 53
30	J129	COM 5	COAX	407263	40"	COM 5
4 Goodyear St., Irvine, CA 92718						
DOCUMENT TITLE			SIZE	CODE NO.	DOCUMENT NO.	REV
HARNESS ASSEMBLY, 1260-54C, TTI			A	21793	407292	A
			DRN		SHEET 5 of 5	

DOC. NO. 407292